BUILT FOR FLORIDA'S RAIN

Don't Worry About Rain Season

Your Pool's Automatic Drainage System

Every Liquid Luxe pool includes a standard automatic drainage system. During construction we install a well point connected to your skimmer through a 1" overflow line that runs about two feet under the paver deck. When heavy rain fills the pool past the skimmer, the excess water drains on its own through this system — no manual pumping, no risk of it overflowing into your yard or toward the house.



Good to know: the well point pipe is installed once, during excavation, and needs no maintenance from you — it's part of your pool's plumbing from day one.