OPTIONAL UPGRADE

# Never Worry About Low Water Level

## Your Pool's Automatic Fill System

An automatic fill system keeps your pool topped off on its own during dry spells and normal evaporation. A backflow preventer, required by code, connects your home's potable water supply to a 1" line that feeds a mechanical autofill valve with a float. When the water level drops, the float opens and lets clean water in; once it reaches the right level, it closes on its own — no more topping it off with a hose.




**This feature does not come included.** It's a plumbing upgrade and requires a separate sub permit and inspection — ask your Project Manager to add it to your contract.